



## CLEANING CARDS FOR COUNTERFEIT DETECTORS

### ENSURE CONTINUED TOP PERFORMANCE

To maintain the best possible performance and make sure counterfeit bills stay out of your business, regular cleaning of your counterfeit detector is a must. The longer and more frequently banknotes are circulated, the more dust and dirt they contain. This grime can impair the operation of your counterfeit detector's integrated sensors and roller system. By regularly using Safescan's counterfeit detector cleaning cards, you keep your detector's internal parts clean, and you can continue to reliably check banknotes' authenticity.


- Cleaning card system for counterfeit detectors
- Regular cleaning ensures continuous trouble-free operation
- 2 different types of cleaning cards for optimal cleaning result
- Cleans the transport mechanism
- Contains water-based cleaning liquid - no chemical substances
- Simply feed the cleaning cards through the detector like a standard banknote
- Cards are packed into airtight sleeves



Cleaning cards for automatic counterfeit detectors



2 different types of cleaning cards for optimal cleaning result



Water based cleaning cards - no chemicals



## **SPECIFICATIONS**

- Cleaning card system for counterfeit detectors
  - Regular cleaning ensures continuous trouble - free operation
  - 2 different types of cleaning cards for optimal cleaning result
  - Cleans the magnetic heads and sensors that lay on the surface of the detector
  - Cleans the transport mechanism
  - Contains water-based cleaning liquid - no chemical substances
  - Simply feed the cleaning cards through the detector like a standard banknote
  - Cards are packed into airtight sleeves
  - Dimensions product: 23 x 15.2 x 2.6 cm (lxwxh)
  - Weight: 250 gr
- 

## **PACKAGE CONTENTS**

- Safescan Cleaning cards
  - 10x Counterfeit Detector Cleaning Card no. 1
  - 10x Counterfeit Detector Cleaning Card no. 2
-