



# 4141T1 CASH DRAWER TRAY

## SPEED UP SHIFT CHANGES AND CASH COUNTING

Buy a spare 4141T1 cash tray and save time on both ends of a shift change. Simply lift the whole 4141T1 out of the cash drawer and slip in the new one, pre-stocked with the desired coins and banknotes to start a new shift. Take the old one to your secure area for easy counting, then prepare it for the next shift and lock it in your safe. Voilà! Shift changes couldn't be more efficient.

- 4 adjustable banknote compartments
- Strong metal money clips
- Removable tray with 8 adjustable coin compartments
- Separation slot for storage of large denominations and value papers



Cash Drawer tray for Safescan SD-4141 and HD-4141S



Robust metal money clips



Removable and adjustable tray for 8 different coins

## TECHNICAL SPECIFICATIONS

|                                 |   |
|---------------------------------|---|
| - Material                      | Robust metal construction   |
| - Inner tray                    | Removable tray with 8 adjustable coin compartments                  |
| - Note compartments             | 4 adjustable banknote compartments                                  |
|                                 | Strong metal money clips  |
| - Security lock                 | Separation slot for storage of large denominations and value papers |
| - Weight product                | 1.2 kg  |
| - Dimensions product (lxwxh)    | 35.8 x 32.8 x 6.4 cm  |
| - Dimensions retailbox (lxwxh)  | 40.2 x 38.2 x 11.5 cm   |
| - Certifications / compliancies | CE, RoHS  |

---

## PACKAGE CONTENTS

- Safescan 4141T1

## WARRANTY

- 1 year

