



4141T

CASH DRAWER TRAY

SPEED UP SHIFT CHANGES AND CASH COUNTING

Buy a spare 4141T cash tray and save time on both ends of a shift change. Simply lift the whole tray out of the cash drawer and slip in the new one, pre-stocked with the desired coins and bills to start a new shift. Take the old one to your secure area for easy counting, then prepare it for the next shift and lock it in your safe. Voilà! Shift changes couldn't be more efficient.

- 5 adjustable bill compartments
- Strong metal money clips
- Removable tray with 5 adjustable coin compartments
- Separation slot for storage of large denominations and value papers
- Suitable for Safescan SD-4141 cash drawer



Cash Drawer tray for Safescan SD-4141



5 bill / 5 coin lay-out



Removable and adjustable tray for 5 different coins

TECHNICAL SPECIFICATIONS

- Material	Strong metal construction
- Inner tray	Removable tray with 5 adjustable coin compartments
- Note compartments	5 adjustable bill compartments
	Strong metal money clips
- Security lock	Separation slot for storage of large denominations and value papers
- Weight product	42.3 Oz
- Dimensions product (lxwxh)	14.1 x 12.9 x 2.5 inch
- Dimensions retailbox (lxwxh)	15.8 x 15.0 x 4.5 inch
- Certifications / compliancies	CE, RoHS

PACKAGE CONTENTS

- Safescan 4141T2

WARRANTY

- 1 year

